



## Fuel trim

### Short term fuel trim




### Long term fuel trim (idle range / no load)



Adds and subtracts small amounts.

---

### Cruise range / load Fra (later split into frau and frao)



Adds subtracts large numbers.  
 If repairs need to be made start in this section.

---